During warranty period, assistance for replacement or exchange of defective components is available at the place of purchase with receipt or valid proof of purchase. The warranty does not cover repair or exchange of product resulting from misuse, accident, modification, unsuitable physical or operating environment, improper maintenance, or failure caused by non-SilverStone product. The warranty is voided by removal or alteration of product or parts identification labels.

Warranty period is region specific, please contact your reseller or SilverStone authorized distributor for more information.

This instruction will help you make the most out of your product. Please read through it before installation. Also, please keep your product receipt and this instruction in safe place for future reference.

We, SilverStone Technology, hope you will enjoy your product.
If you have any comments or suggestions, please e-mail to **support@silverstonetek.com**
Thank you for choosing and supporting our product.

For Australia only

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Please refer to below for further warranty details. SilverStone Technology Co., Ltd. 12F No. 168 Jiankang Rd., Zhonghe Dist., New Taipei City 235 Taiwan R.O.C. + 886-2-8228-1238 (standard international call charges apply)

1.Product component defects or damages resulted from defective production is covered under warranty. Defects or damages with the following conditions will be fixed or replaced under SilverStone Technology's jurisdiction.
(a) Usage in accordance with instructions provided in this manual, with no misuse, overuse, or other inappropriate actions.
(b) Damage not caused by natural disaster (thunder, fire, earthquake, flood, salt, wind, insect, animals, etc…)
(c) Product is not disassembled, modified, or fixed. Components not disassembled or replaced.
(d) Warranty mark/stickers are not removed or broken.
Loss or damages resulted from conditions other than ones listed above are not covered under warranty.

2.Under warranty, SilverStone Technology's maximum liability is limited to the current market value for the product (depreciated value, excluding shipping, handling, and other fees). SilverStone Technology is not responsible for other damages or loss associated with the use of product.

3.Under warranty, SilverStone Technology is obligated to repair or replace its defective products. Under no circumstances will SilverStone Technology be liable for damages in connection with the sale, purchase, or use including but not limited to loss of data, loss of business, loss of profits, loss of use of the product or incidental or consequential damage whether or not foreseeable and whether or not based on breach of warranty, contract or negligence, even if SilverStone Technology has been advised of the possibility of such damages.

4.Warranty covers only the original purchaser through authorized SilverStone distributors and resellers and is not transferable to a second hand purchaser

5.You must provide sales receipt or invoice with clear indication of purchase date to determine warranty eligibility.

6.Unless otherwise noted, the limited warranty detail as below
(a)All SilverStone retail boxed power supply products (excluding power supply sold as part of a case product) come with 3 year warranty from the date of purchase.
(b)All SilverStone retail case products that have power supply included come with 1 year warranty from the date of purchase.
(c)All SilverStone retail storage and accessory products (excluding expendable material) come with 1 year warranty from the date of purchase.

7.If a problem develops during the Warranty Period, please contact your retailer/reseller/SilverStone authorized distributors or SilverStone http://www.silverstonetek.com. Please note that: (i) You must provide proof of original purchase of the Product by a dated itemized receipt; (ii) You shall bear the cost of shipping (or otherwise transporting) the Product to SilverStone authorized distributors. SilverStone authorized distributors will bear the cost of shipping (or otherwise transporting) the Product back to you after completing the warranty service; (iii) Before you send the Product, you must be issued a Return Merchandise Authorization ("RMA") number from SilverStone. Updated warranty information will be posted on SilverStone's official website. Please visit http://www.silverstonetek.com for the latest updates.

SilverStone Technology Co., Ltd.

www.silverstonetek.com

support@silverstonetek.com
Issue date: October, 2012
NO:G11217380

SILVERSTONE®
Designing Inspiration

RL04
REDLINE SERIES

Special Features

- Positive pressure design for effective dust reduction
- Removable dust filter for top and bottom vents
- Smart backside cable routing design
- Motherboard back plate opening for quick CPU cooler assembly
- Support easy access drive bays with tool-less design
- All black painting inside with stylish look
- Highly flexible drive storage options
- Support seven expansion slots cards up to 11.5 inches long



PICTURE	ITEM	PURPOSE
	SCREW-H/W-6-32*6-BK	SECURE PSU,3.5" HDD,MB,EXPANSION SLOTS
	STANDOFF-6-32*6.5H-6-32	SUPPORT MB
	SCREW-P/W-M3*4-BK	SECURE 2.5" HDD

Optical drive installation



ENGLISH
Remove the 5.25" drive bay covers as indicated in the diagram.
Install your optical drive or 5.25" device as indicated in the diagram.
(Insert the optical drive externally and secure with the brackets from both sides)

DEUTSCH
Entfernen Sie die Abdeckungen der 5,25-Zoll-Laufwerkseinschübe wie in der Abbildung gezeigt.
Installieren Sie das optische Laufwerk oder 5,25-Zoll-Gerät wie in der Abbildung gezeigt.
(Setzen Sie das optische Laufwerk extern ein; sichern Sie es von beiden Seiten mit den Halterungen)

FRANÇAIS
Retirez les caches des baies de lecteur 5,25'' tel qu'illustré.
Installez votre lecteur optique ou un périphérique 5,25" comme indiqué dans l'illustration.
(Insérez le lecteur optique externe et sécurisez-le à l'aide des supports de part et d'autre)

ESPAÑOL
Retire las cubiertas para bahía de dispositivos de 5,25" como se indica en el diagrama.
Instale la unidad óptica o el dispositivo de 5,25" tal y como se indica en el diagrama.
(Inserte el dispositivo óptico externamente y fíjelo con los brackets desde ambos lados)

ITALIANO
Rimuovere le coperture dell'unità 5,25", come indicato nella figura.
Installare l'unità ottica o il dispositivo da 5,25" come indicato nello schema.
(Inserire l'unità ottica esterna e fissarla con i supporti su entrambi i lati)

РУССКИЙ
Снимите крышку отсека 5,25-дюймовых дисков, как показано на рисунке.
Установите оптический привод или 5,25-дюймовое устройство, как показано на схеме.
(Установите с внешней стороны оптический привод и закрепите его винтами с обеих сторон)

繁體中文
請依圖示由面板正面取下擋版
依圖示安裝你的光碟機或5. 25吋裝置
（由外部將光碟機推入機身與面板平齊，於兩側鎖上扣具）

日 本 語
図示されるように5. 25” ドライブベイカバーを取り外します。
ご使用の光学ドライブあるいは5. 25” デバイスを、図の通りに設置します。
（光学ドライブは外側から装着し、ブラケット両側のネジで固定します）

한 국 어
그림과 같이 5.25" 드라이브 베이 커버를 분리합니다.
광학 드라이브나 5.25" 기기들을 다이어그램에 나타난 대로 설치하십시오.
(밖에서 광드라이브를 삽입하고 양쪽에서 브래킷으로 고정합니다.)



简体中文
请依图示由面板正面取下挡版
依图标安装你的光驱或5. 25吋装置
（由外部将光驱推入机身与面板平齐，于两侧锁上扣具）



Hard drive installation





ENGLISH
- Remove the hard drive bracket as indicate in the diagram.
  Install your 3.5" drive and secure with screws from both sides.
- Remove the hard drive bracket as indicate in the diagram.
  Install your 2.5" drive and secure with screws from the bottom.

DEUTSCH
- Entfernen Sie die Festplattenhalterung wie in der Abbildung gezeigt.
  Installieren Sie Ihr 3,5-Zoll-Laufwerk, befestigen Sie es von beiden Seiten mit Schrauben.
- Entfernen Sie die Festplattenhalterung wie in der Abbildung gezeigt.
  Installieren Sie Ihr 2,5-Zoll-Laufwerk, befestigen Sie es von der Unterseite mit Schrauben.

FRANÇAIS
- Retirez le support du lecteur tel qu'illustré.
  Insérez votre lecteur de 3,5" et sécurisez-le à l'aide de vis des deux côtés.
- Retirez le support du lecteur tel qu'illustré.
  Insérez votre lecteur de 2,5" et sécurisez-le à l'aide de vis depuis le bas.

ESPAÑOL
- Retire el bracket para discos duros como se indica en el diagrama.
  Instale su disco de 3,5" y fíjelo con tornillos a ambos lados.
- Retire el bracket para discos duros como se indica en el diagrama.
  Instale su dispositivo de 2,5" y fíjelo con tornillos desde abajo

ITALIANO
- Rimuovere il supporto del disco rigido come indicato nella figura.
  Installare l'unità 3,5" e fissarla con le viti su entrambi i lati.
- Rimuovere il supporto del disco rigido come indicato nella figura.
  Installare l'unità 2,5" e fissarla con le viti su entrambi sul lato inferiore.

РУССКИЙ
- Снимите кронштейн жесткого диска, как показано на рисунке.
  Установите 3,5-дюймовый диск и закрепите его винтами с обеих сторон.
- Снимите кронштейн жесткого диска, как показано на рисунке.
  Установите 2,5-дюймовый диск и закрепите его винтами снизу.

繁體中文
- 請依圖示將硬碟拖盤取出，然後放入3. 5” 硬碟，再於兩側鎖上螺絲固定
- 請依圖示將硬碟拖盤取出，然後放入2. 5” 硬碟，再於底部鎖上螺絲固定

日 本 語
- 図示されるようにハードディスクドライブブラケットを取り外します。
  3.5” ドライブを装着し、両側からネジで固定します。
- 図示されるようにハードディスクドライブブラケットを取り外します。
  2.5” ドライブを装着し、底部からネジで固定します。

한 국 어
- 그림과 같이 하드 드라이브 브래킷을 분리합니다.
  3.5” 드라이브를 설치하고 양쪽에서 나사로 고정합니다.
- 그림과 같이 하드 드라이브 브래킷을 분리합니다.
  2.5” 드라이브를 설치하고 하단에서 나사로 고정합니다.

简体中文
- 请依图标将硬盘拖盘取出，然后放入3. 5” 硬盘，再于两侧锁上螺丝固定
- 请依图标将硬盘拖盘取出，然后放入2. 5” 硬盘，再于底部锁上螺丝固定